



AEROMACH MANUFACTURING
800 990-9392 WWW.AEROMACHMFG.COM
619 258-5443 619 258-8515 FAX

INSTALLATION FOR WARHEADS

Slide Billet Warheads up front fork tubes from bottom until they seat. Tighten (2) set screws using 3mm allen wrench until tight. Locktite is recommended.

To protect your chrome, use a carnubar wax on the chrome and clean after every ride.

Honda models will require a bolt kit (AM-5005) to replace the stock for pinch bolts (2) on each fork.