



AEROMACH MANUFACTURING

MOTORCYCLE DIVISION

11423 B Woodside ave.
Santee, Ca. 92071
(800) 990-9392
(619) 258-5443 FAX (619) 258-8515
email: jeff@aeromach.net
www.aeromach.net

Install Guide for PullBack Risers

1. Cover gas tank with a towel to avoid scratching.
2. Loosen bottom bolts to stock risers first.
3. Have a friend hold onto handle bars while loosening the top clamp bolts.
4. Remove stock risers.
5. From the bottom, pass bolt (provided) through triple tree.
6. Thread bolt into the bottom of the pullback riser but do not over-tighten yet
7. Position handlebars into risers and tighten down.
8. Now do final tightening to the bolts below the risers.
9. Adjust bar height to comfort.

**CLEAN RISERS WITH CHROME CLEANER 1 X WEEK AND
POLISH WITH STRAIGHT CARNAUBA WAX. CHROME IS FRAGILE AND
SUSCEPTIBLE TO CORROSIVES LIKE BRAKE FLUID, BATTERY ACID,
ANTI-FREEZE AND EVEN BRAKE PAD DUST.**