

AEROMACH MANUFACTURING 800 990-9392
HONDA VTX C MODEL PULLBACK RISER
INSTALLATION GUIDE

6" Pullback Riser Set AM-3490P

Tools Needed:

- Friend to hold handlebars
- Large Towel
- Breaker Bar
- Metric Allen Wrenches - 6mm & 10 mm
- 19mm socket on box wrench

Stock Riser Removal and Aeromach Riser Installation:

1. To simplify stock riser bolt removal, turn front wheel to opposite direction of bolt being removed.
2. Cover gas tank with towel to avoid scratching.
3. Loosen bolts under triple tree using 19mm socket and breaker bar.
4. Remove bolts from the top clamp speedo while a friend holds the handlebars.
5. *DO NOT DETACH ANY CABLES!!*
6. Remove nuts under triple tree and pull stock risers free.
7. Push Aeromach furnished bolt & washer up from underneath triple tree.
8. Finger tighten bolts to riser bodies.
9. Loosely assemble stock speedo housing to riser bodies using stock bolts.
10. Adjust handle bars to a comfortable position.
11. Securely tighten speedo housing bolts and replace chrome bolt head covers (hot toppers).
12. Securely tighten riser body bolts under triple tree with breaker bar.

GO RIDE!!