

Bullet Tachometer Install on Honda VTX 1300

Tools Needed:

M4 Allen Wrench
Philips Screwdriver
Crimpers
Wire Stripers
Diagonals

Install:

1. Bolt on the Bullet Tachometer and center it between the risers. Run the wires so that the travel cleanly into the rear opening of the headlight.
2. Open up the headlight to access the wires inside.
3. The **Red** and **Blue** wires from the tach are the power and tach operation wires. Tie them together. The **Black** wire from the tach is the ground.
4. Connect the **Red** and **Blue** wires from the tach to the **Black w/ Brown** wire and the **Black** wire from the tach to the **Green** wire. Use the butt splices provided to attach.
5. Push the wires back into the headlight bucket and replace screws.
6. Remove seat. Remove rear gas tank bolt and lift left side of tank up to expose the engine coil. It is located in the left corner, under the tank.
7. Connect the green wire from tach to blue w/white strip coil wire.