



**AEROMACH MANUFACTURING**  
**800 990-9392 WWW.AEROMACH.NET**

**INSTALL GUIDE FOR AM-8260SSP**

1. Clean the OEM floorboard rubber with rubbing alcohol and let it air dry.
2. Cut the inserts out of their holders.
3. Remove the white protective paper prior to gluing.
4. Silicone is the best adhesive to use. You can find it at any Home Depot store. Glue only one insert at a time by dabbing a small amount of siliconeP in the rubber groove or directly onto the back of the insert.
5. Be sure to smear the glue to cover the most area possible. Press the insert into the respective groove quickly; the glue sets up fast.
6. Hold the insert down into the groove for 30 seconds using normal to stern hand pressure.
7. Use rubbing alcohol, nail polish remover or acetone to clean any excess glue that may be on the surface.